


ASHFORD 2 SPEED DRUM CARDER



The Ashford Drum Carder - Fine or Coarse

Prepare 50gm (2ozs) batts quickly and efficiently. Ideal for spinning or felting.

The two-speed ratios give flexibility and control when carding and blending.

Use the 6:1 ratio to prepare your fleece. The controlled intake and carding will produce a smooth even batt ready for blending, spinning or felting.

Use the 4:1 ratio to blend sliver, colours and different fibre types consistently into an open and airy batt.

The adjustable drum clearance allows you to set the teeth distance for total control of your fibre. All nylon bearings ensure it is light and easy to turn.

The card cloth has wire teeth with a special protective coating and a flexible rubber backing for long life. The carder is strong and robust with the body made from Silver Beech hardwood. The carder has rubber feet to prevent it slipping. It comes assembled and lacquered ready to use.

Attach the handle as shown. Place a spring washer on first, thread on the handle, the second spring washer and lock in place with the nylon knob.

Thread the 2 screw eyes into the holes in the side of the carder. Use them to store the doffer.

Place the drive band onto the pulleys as illustrated.

NOTE: To avoid the drive cord stretching when not in use, please loosen the drive cord by moving it to a smaller pulley.

ADC290413V7

Ashford Handicrafts Ltd.

Factory and Showroom: 415 West Street,

PO Box 474, Ashburton, New Zealand







Telephone 64 3 308 9087 Facsimile 64 3 308 8664

Email: sales@ashford.co.nz Internet: www.ashford.co.nz


Ashford Guarantee

Thank you for purchasing this Ashford product. In the unlikely event there is any fault in manufacture we will replace the item. To validate our guarantee please visit our website or write to us. Please also join our Ashford Club for the Wheel Magazine, competitions and more at www.ashfordclub.co.nz


HOW TO USE




CHECK!




8



9



10



Hints!



Ashford Rainbow sliver

Second Carding


Mixing Colours

Rolags


Felting




MAINTAINING



Oil



Cleaning -Carding cloth-





Cleaning


-Drum shafts-

If you find the handle hard to turn...


You will need...




1




2




3



4




5




REASSEMBLING CHECK!


6




7



8





9







ADJUSTING

-Gap between teeth-

You will need...



NOTE!



Hint!

To wash wool

The dirt and grease in unwashed wool can reduce the life of the carder.
Washed wool keep the carding cloth and teeth free from grease and grime.

